

Stage

Retractable Riser:
Completely flush w/ stage front,
OR, can be 18' deep if fully extended

Dance Floor
43' long x 19' wide
without riser out

Leave this area
Open for Bar
Access and →
Kitchen Service

